

## TUTORIAL



TITLE

### SKINNY BROWN PANTS WITH CREASE

FROM THE FEATURE

Miele

SISTERMAG

N°29

HIP WIDTH 92

### MATERIALS


- » 1 m wool georgette or a different kind of heavy fabric with elastane
- » Zip 20 cm
- » 1 Button

### HOW-TO

1. Stretch the creases created through steam ironing at the back part of the trousers
2. Iron creases into front parts
3. Put darts into back parts of the trousers
4. Sew inner and outer seam, on the left side only up to the zip markings
5. Sew in zip and try on
6. Determine the width of the waistband und cut your fabric accordingly Length+ 3cm Underlay+ 2cm seam allowance 7 cm width.
7. Adjust the fit of the trousers by changing the width of your seams
8. Sew and attach waistband
9. Sew the button hole and attach button
10. Pin the length of your trousers, iron it and seam it invisibly by hand
11. Iron creases



## CUTTING PATTERN - OVERVIEW



■ vorderes Hosenteill 2x / front trousers panel 2x



■ hinteres Hosenteill 2x / back trousers panel 2x

# Braune schmale Hose

Ausgabe 29 // Issue 29 05 - 17


■ vorderes Hosenteil 2x / front trousers panel 2x

■ hinteres Hosenteil 2x / back trousers panel 2x




e Seite


2



3



5





6

Bügefalte

7







Verlängern um 5 cm

8